

These instructions are to retrieve 3 information files from FANUC controls:  
MAINTINF.txt, SYS\_CONF.txt, and CNC\_ID.txt.

## 1.) Maintenance Info Backup

The I/O channel must be set to 4, and EDIT mode selected, to use the ALL I/O screen.



1) Press the left CNC soft key, to exit the OPRT menu.

2) Press the right CNC soft key, to change the menu.

3) Press the soft key on the CNC menu.

4) Press the soft key on the CNC menu.

5) Press the soft key on the CNC menu.

6) Press the soft key on the CNC menu.

OUTPUT will as the data is being sent, the **MAINTINF.TXT** file is created.

## 2.) System Info (Sys Config)

1) Press the System hard key

2) Press the System soft key

3) Press the Soft key on the CNC menu

4) Press the Soft key on the CNC menu

5) Press the Soft key on the CNC menu

File name is **SYS\_CONF.TXT**

ACTUAL POSITION

00003 N00000

The screenshot shows the FANUC CNC control panel with the following details:

- Actual Position:** 00003 N00000
- Coordinate Axes:** X, Y, Z, A, C (absolute values: 0.000)
- Velocity:** 0 MM/MIN
- Modal G-codes:** G00, G80, G15, G17, G98, G640.1H, G90, G50, G25, G22, G67, G160, G94, G97, G13.1S, G21, G54, G50.1, G40, G64, G54.2, G49, G69, G80.5
- System Configuration (Hardware) Screen:**
  - MAIN BOARD:** MAIN BOARD 0032B 30 0, CPU CARD 00419 40 2 70020102, SERVO CARD 0010B 20 1, PMC MODULE 00700 30 0, FROM/SRAM C3/04
  - OPTION BOARD:** ETHER/DTSVR 00701 30 1
  - DISPLAY:** DISP ID 1010
  - OTHERS:** MDI ID 02, B.UNIT ID 10
- Bottom Control Bar:** Includes buttons for ABSOLUTE, RELATIVE, ALL, PUNCH, and EDIT. The EDIT button is highlighted.
- Time:** 01:14:41

### 3.) CNC ID Info

- 1) Press the “System hard key”
  - 2) Press the  until “ID-INF” appears
  - 3) Push the  soft key
  - 4) Push the  soft key
  - 5) Push the  soft key
- The CNC ID data is saved onto the memory card. The file name is **CNCIDNUM.TXT**.