BTS, Inc.

Technical Bulletin

Date: 2/22/13

RE: Upgrading DNCPro from 5.0x to 6.0x

1). All DNCPro applications need to be closed on the Server and all clients before running the upgrade.

2). Run the installation program from the CD. If Auto-run is disabled, the Installation program (DNCPRO_Server.exe) is found under the DNCProfessional folder. You must have local Admin rights to run the upgrade.

See the DNCPro 6.0x Server installation using MS-Access Database.doc located on the CD for detailed instructions.

3). Install the DNCPro software. After installation is complete, restart the Server/PC.

4). Once the installation is complete, using the DNCPro 6.0x CD, browse to the Update folder. Start the UpgradeDriver.exe application.

This application will check the version of DNCPro that was running before the upgrade. It will then step thru each update. You will need to manually respond to each step of the update. Once the database updates are finished, it will automatically convert the Dbase IV files to MS Access.

5). Restart the PC/Server to complete the update.

6). If running DNCPro on any workstations, you will need to run the client\setup program on each client. This update is found in the DNCPro\ClientD directory. Start the Setup.exe program.

See the Workstation installation using MS-Access Database.doc located on the CD for detailed instructions.